

OsmoHLR VTY Reference

Copyright © 2017

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

COLLABORATORS

	<i>TITLE :</i> OsmoHLR VTY Reference	
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>
WRITTEN BY		August 29, 2020

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
v1	18th September 2017	Initial	nh

Contents

1	VTY reference	1
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list	2
1.1.5	show running-config	3
1.1.6	write	3
1.1.7	write file	3
1.1.8	write memory	4
1.1.9	write terminal	4
1.2	view	4
1.2.1	enable	4
1.2.2	logging color (0 1)	5
1.2.3	logging disable	5
1.2.4	logging enable	5
1.2.5	logging filter all (0 1)	6
1.2.6	logging level (main db au css global lapd linp mux m mib lms m ctrl gtpl 	6
1.2.7	logging level force-all (debug info notice error fatal)	8
1.2.8	logging level set-all (debug info notice error fatal)	9
1.2.9	logging print category (0 1)	9
1.2.10	logging print category-hex (0 1)	10
1.2.11	logging print extended-timestamp (0 1)	10
1.2.12	logging print file (0 1 basename) [last]	11
1.2.13	logging print level (0 1)	11
1.2.14	logging set-log-mask MASK	12
1.2.15	logging timestamp (0 1)	12
1.2.16	no logging level force-all	12
1.2.17	show alarms	13
1.2.18	show asciidoc counters	13

1.2.19	show gsup-connections	14
1.2.20	show history	14
1.2.21	show logging vty	14
1.2.22	show online-help	15
1.2.23	show rate-counters	15
1.2.24	show stats	15
1.2.25	show stats level (global peer subscriber)	16
1.2.26	show subscriber (imsilmsisdn lid imei) IDENT	16
1.2.27	show talloc-context (application all) (full brief DEPTH)	17
1.2.28	show talloc-context (application all) (full brief DEPTH) filter REGEXP	17
1.2.29	show talloc-context (application all) (full brief DEPTH) tree ADDRESS	18
1.2.30	show version	19
1.2.31	subscriber (imsilmsisdn lid imei) IDENT show	19
1.2.32	terminal length <0-512>	20
1.2.33	terminal no length	20
1.2.34	who	20
1.3	enable	21
1.3.1	configure terminal	21
1.3.2	copy running-config startup-config	21
1.3.3	disable	21
1.3.4	logging color (0 1)	22
1.3.5	logging disable	22
1.3.6	logging enable	22
1.3.7	logging filter all (0 1)	23
1.3.8	logging level (main db auc ssl global lapd inp mux lmi mib lms ctrl gtp ...)	23
1.3.9	logging level force-all (debug info notice error fatal)	25
1.3.10	logging level set-all (debug info notice error fatal)	26
1.3.11	logging print category (0 1)	26
1.3.12	logging print category-hex (0 1)	27
1.3.13	logging print extended-timestamp (0 1)	27
1.3.14	logging print file (0 1 basename) [last]	28
1.3.15	logging print level (0 1)	28
1.3.16	logging set-log-mask MASK	29
1.3.17	logging timestamp (0 1)	29
1.3.18	no logging level force-all	29
1.3.19	show alarms	30
1.3.20	show asciidoc counters	30
1.3.21	show gsup-connections	31
1.3.22	show history	31

1.3.23	show logging vty	31
1.3.24	show online-help	32
1.3.25	show rate-counters	32
1.3.26	show startup-config	32
1.3.27	show stats	33
1.3.28	show stats level (global peer subscriber)	33
1.3.29	show subscriber (imsilmsisdnlid imei) IDENT	33
1.3.30	show talloc-context (application all) (full brief DEPTH)	34
1.3.31	show talloc-context (application all) (full brief DEPTH) filter REGEXP	35
1.3.32	show talloc-context (application all) (full brief DEPTH) tree ADDRESS	35
1.3.33	show version	36
1.3.34	subscriber (imsilmsisdnlid imei) IDENT delete	36
1.3.35	subscriber (imsilmsisdnlid imei) IDENT show	37
1.3.36	subscriber (imsilmsisdnlid imei) IDENT update aud2g (comp128v1 comp128v2 comp128v3)	37
1.3.37	subscriber (imsilmsisdnlid imei) IDENT update aud2g none	38
1.3.38	subscriber (imsilmsisdnlid imei) IDENT update aud3g milenage k K (oplopc) OP_C [...].	39
1.3.39	subscriber (imsilmsisdnlid imei) IDENT update aud3g none	40
1.3.40	subscriber (imsilmsisdnlid imei) IDENT update imei (none IMEI)	41
1.3.41	subscriber (imsilmsisdnlid imei) IDENT update msisdn (none MSISDN)	42
1.3.42	subscriber (imsilmsisdnlid imei) IDENT update network-access-mode (none cs pslcs pslcs+)	42
1.3.43	subscriber imsi IDENT create	43
1.3.44	terminal length <0-512>	44
1.3.45	terminal monitor	44
1.3.46	terminal no length	44
1.3.47	terminal no monitor	45
1.3.48	who	45
1.4	config	45
1.4.1	banner motd default	45
1.4.2	banner motd file [FILE]	46
1.4.3	ctrl	46
1.4.4	enable password (8l) WORD	46
1.4.5	enable password LINE	47
1.4.6	hlr	47
1.4.7	hostname WORD	47
1.4.8	line vty	48
1.4.9	log alarms <2-32700>	48
1.4.10	log file .FILENAME	48
1.4.11	log gsmtap [HOSTNAME]	49
1.4.12	log stderr	49

1.4.13	log syslog (authpriv cron daemon ftp lpr mail news user uucp)	49
1.4.14	log syslog local <0-7>	50
1.4.15	no banner motd	51
1.4.16	no enable password	51
1.4.17	no hostname [HOSTNAME]	51
1.4.18	no log alarms	52
1.4.19	no log file .FILENAME	52
1.4.20	no log stderr	52
1.4.21	no log syslog	53
1.4.22	no service advanced-vty	53
1.4.23	no service terminal-length [<0-512>]	53
1.4.24	no stats reporter log	54
1.4.25	no stats reporter statsd	54
1.4.26	password (8) WORD	54
1.4.27	password LINE	55
1.4.28	service advanced-vty	55
1.4.29	service terminal-length <0-512>	55
1.4.30	show history	56
1.4.31	stats interval <1-65535>	56
1.4.32	stats reporter log	57
1.4.33	stats reporter statsd	57
1.5	config-log	57
1.5.1	logging color (0 1)	58
1.5.2	logging filter all (0 1)	58
1.5.3	logging level (main db aucl ssl global lapd linp mux mills mib lmsms ctrl gtpl ...)	59
1.5.4	logging level force-all (debug info notice error fatal)	60
1.5.5	logging level set-all (debug info notice error fatal)	61
1.5.6	logging print category (0 1)	62
1.5.7	logging print category-hex (0 1)	62
1.5.8	logging print extended-timestamp (0 1)	63
1.5.9	logging print file (0 1 basename) [last]	63
1.5.10	logging print level (0 1)	64
1.5.11	logging timestamp (0 1)	64
1.5.12	no logging level force-all	65
1.6	config-stats	65
1.6.1	disable	65
1.6.2	enable	65
1.6.3	level (global peer subscriber)	66
1.6.4	local-ip ADDR	66

1.6.5	mtu <100-65535>	66
1.6.6	no local-ip	67
1.6.7	no mtu	67
1.6.8	no prefix	67
1.6.9	prefix PREFIX	68
1.6.10	remote-ip ADDR	68
1.6.11	remote-port <1-65535>	68
1.7	config-line	69
1.7.1	bind A.B.C.D [<0-65535>]	69
1.7.2	login	69
1.7.3	no login	69
1.8	config-ctrl	70
1.8.1	bind A.B.C.D	70
1.9	config-hlr	70
1.9.1	database PATH	70
1.9.2	euse NAME	70
1.9.3	gsup	71
1.9.4	ncss-guard-timeout <0-255>	71
1.9.5	no euse NAME	71
1.9.6	no store-imei	72
1.9.7	no subscriber-create-on-demand	72
1.9.8	no ussd default-route	72
1.9.9	no ussd route prefix PREFIX	73
1.9.10	store-imei	73
1.9.11	subscriber-create-on-demand (no-msisdn<3-15>) (none lcs ps lcs+ps)	73
1.9.12	ussd default-route external EUSE	74
1.9.13	ussd route prefix PREFIX external EUSE	74
1.9.14	ussd route prefix PREFIX internal (own-msisdn own-imsi)	75
1.10	config-hlr-gsup	76
1.10.1	bind ip A.B.C.D	76
1.11	config-hlr-euse	76

List of Tables

1.1	VTY Parameter Patterns	1
1.2	VTY port numbers	1

Chapter 1

VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

1.1.1 end

Command

```
end
```

Parameters

end

End current mode and change to enable mode.

1.1.2 exit

Command

```
exit
```

Parameters

exit

Exit current mode and down to previous mode

1.1.3 help

Command

```
help
```

Parameters

help

Description of the interactive help system

1.1.4 list

Command

```
list
```

Parameters

list

Print command list

1.1.5 show running-config

Command

```
show running-config
```

Parameters

show

 Show running system information

running-config

 running configuration

1.1.6 write

Command

```
write
```

Parameters

write

 Write running configuration to memory, network, or terminal

1.1.7 write file

Command

```
write file
```

Parameters

write

 Write running configuration to memory, network, or terminal

file

 Write to configuration file

1.1.8 write memory

Command

```
write memory
```

Parameters

write

 Write running configuration to memory, network, or terminal

memory

 Write configuration to the file (same as write file)

1.1.9 write terminal

Command

```
write terminal
```

Parameters

write

 Write running configuration to memory, network, or terminal

terminal

 Write to terminal

1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

1.2.1 enable

Command

```
enable
```

Parameters

enable

 Turn on privileged mode command

1.2.2 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

1.2.3 logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

1.2.6 logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...

Command

```
logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵
    lgsup|loap|lss7|lscap|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ↵
    fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

main

Main Program

db

Database Layer

auc	Authentication Center
ss	Supplementary Services
lglobal	Library-internal global log family
llapd	LAPD in libosmogsm
linp	A-bis Input Subsystem
lmux	A-bis B-Subchannel TRAU Frame Multiplex
lmi	A-bis Input Driver for Signalling
lmib	A-bis Input Driver for B-Channels (voice)
lsms	Layer3 Short Message Service (SMS)
lctrl	Control Interface
lgtp	GPRS GTP library
lstats	Statistics messages and logging
lgsup	Generic Subscriber Update Protocol
loap	Osmocom Authentication Protocol
lss7	libosmo-sigtran Signalling System 7
lsccp	libosmo-sigtran SCCP Implementation
lsua	libosmo-sigtran SCCP User Adaptation
lm3ua	libosmo-sigtran MTP3 User Adaptation
lmgcp	libosmo-mgcp Media Gateway Control Protocol

ljbuf

libosmo-netif Jitter Buffer

lrspro

Remote SIM protocol

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

1.2.7 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

1.2.8 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

1.2.9 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

1.2.10 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

1.2.11 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

1.2.12 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

1.2.13 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

1.2.14 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL_DEBUG=1 LOGL_INFO=3 LOGL_NOTICE=5 LOGL_ERROR=7 LOGL_FATAL=8

1.2.15 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

1.2.16 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

1.2.17 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

1.2.18 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

1.2.19 show gsup-connections

Command

```
show gsup-connections
```

Parameters

show

 Show running system information

gsup-connections

 GSUP Connections from VLRs, SGSNs, EUSES

1.2.20 show history

Command

```
show history
```

Parameters

show

 Show running system information

history

 Display the session command history

1.2.21 show logging vty

Command

```
show logging vty
```

Parameters

show

 Show running system information

logging

 Show current logging configuration

vty

 Show current logging configuration for this vty

1.2.22 show online-help

Command

```
show online-help
```

Parameters

show

 Show running system information

online-help

 Online help

1.2.23 show rate-counters

Command

```
show rate-counters
```

Parameters

show

 Show running system information

rate-counters

 Show all rate counters

1.2.24 show stats

Command

```
show stats
```

Parameters

show

 Show running system information

stats

 Show statistical values

1.2.25 show stats level (global|peer|subscriber)

Command

```
show stats level (global|peer|subscriber)
```

Parameters

show

 Show running system information

stats

 Show statistical values

level

 Set the maximum group level

global

 Show global groups only

peer

 Show global and network peer related groups

subscriber

 Show global, peer, and subscriber groups

1.2.26 show subscriber (imsi|msisdn|id|imei) IDENT

Command

```
show subscriber (imsi|msisdn|id|imei) IDENT
```

Parameters

show

 Show running system information

subscriber

 Subscriber management commands

imsi

 Identify subscriber by IMSI

msisdn

 Identify subscriber by MSISDN (phone number)

id

 Identify subscriber by database ID

imei

 Identify subscriber by IMEI

IDENT

 IMSI/MSISDN/ID/IMEI of the subscriber

1.2.27 show talloc-context (application|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

Parameters

show

 Show running system information

talloc-context

 Show talloc memory hierarchy

application

 Application's context

all

 All contexts, if NULL-context tracking is enabled

full

 Display a full talloc memory hierarchy

brief

 Display a brief talloc memory hierarchy

DEPTH

 Specify required maximal depth value

1.2.28 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show

 Show running system information

talloc-context

 Show talloc memory hierarchy

application

 Application's context

all

 All contexts, if NULL-context tracking is enabled

full

 Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

filter

Filter chunks using regular expression

REGEXP

Regular expression

1.2.29 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

1.2.30 show version

Command

```
show version
```

Parameters

show

 Show running system information

version

 Displays program version

1.2.31 subscriber (imsi|msisdn|id|imei) IDENT show

Command

```
subscriber (imsi|msisdn|id|imei) IDENT show
```

Parameters

subscriber

 Subscriber management commands

imsi

 Identify subscriber by IMSI

msisdn

 Identify subscriber by MSISDN (phone number)

id

 Identify subscriber by database ID

imei

 Identify subscriber by IMEI

IDENT

 IMSI/MSISDN/ID/IMEI of the subscriber

show

 Show subscriber information

1.2.32 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

 Set terminal line parameters

length

 Set number of lines on a screen

<0-512>

 Number of lines on screen (0 for no pausing)

1.2.33 terminal no length

Command

```
terminal no length
```

Parameters

terminal

 Set terminal line parameters

no

 Negate a command or set its defaults

length

 Set number of lines on a screen

1.2.34 who

Command

```
who
```

Parameters

who

 Display who is on vty

1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

1.3.1 configure terminal

Command

```
configure terminal
```

Parameters

configure

 Configuration from vty interface

terminal

 Configuration terminal

1.3.2 copy running-config startup-config

Command

```
copy running-config startup-config
```

Parameters

copy

 Copy configuration

running-config

 Copy running config to...

startup-config

 Copy running config to startup config (same as write file)

1.3.3 disable

Command

```
disable
```

Parameters

disable

 Turn off privileged mode command

1.3.4 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

1.3.5 logging disable

Command

```
logging disable
```

Parameters

logging

Configure logging

disable

Disables logging to this vty

1.3.6 logging enable

This command is required to make logging commands available on the telnet VTY.

Command

```
logging enable
```

Parameters

logging

Configure logging

enable

Enables logging to this vty

1.3.7 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

1.3.8 logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...

Command

```
logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵
    lgsup|loap|lss7|lscap|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ↵
    fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

main

Main Program

db

Database Layer

auc	Authentication Center
ss	Supplementary Services
lglobal	Library-internal global log family
llapd	LAPD in libosmogsm
linp	A-bis Input Subsystem
lmux	A-bis B-Subchannel TRAU Frame Multiplex
lmi	A-bis Input Driver for Signalling
lmib	A-bis Input Driver for B-Channels (voice)
lsms	Layer3 Short Message Service (SMS)
lctrl	Control Interface
lgtp	GPRS GTP library
lstats	Statistics messages and logging
lgsup	Generic Subscriber Update Protocol
loap	Osmocom Authentication Protocol
lss7	libosmo-sigtran Signalling System 7
lsccp	libosmo-sigtran SCCP Implementation
lsua	libosmo-sigtran SCCP User Adaptation
lm3ua	libosmo-sigtran MTP3 User Adaptation
lmgcp	libosmo-mgcp Media Gateway Control Protocol

ljbuf

libosmo-netif Jitter Buffer

lrspro

Remote SIM protocol

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

1.3.9 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

1.3.10 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

1.3.11 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

1.3.12 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

1.3.13 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

1.3.14 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

1.3.15 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

1.3.16 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL_DEBUG=1 LOGL_INFO=3 LOGL_NOTICE=5 LOGL_ERROR=7 LOGL_FATAL=8

1.3.17 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

1.3.18 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

1.3.19 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

1.3.20 show asciidoc counters

Command

```
show asciidoc counters
```

Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

1.3.21 show gsup-connections

Command

```
show gsup-connections
```

Parameters

show

 Show running system information

gsup-connections

 GSUP Connections from VLRs, SGSNs, EUSES

1.3.22 show history

Command

```
show history
```

Parameters

show

 Show running system information

history

 Display the session command history

1.3.23 show logging vty

Command

```
show logging vty
```

Parameters

show

 Show running system information

logging

 Show current logging configuration

vty

 Show current logging configuration for this vty

1.3.24 show online-help

Command

```
show online-help
```

Parameters

show

 Show running system information

online-help

 Online help

1.3.25 show rate-counters

Command

```
show rate-counters
```

Parameters

show

 Show running system information

rate-counters

 Show all rate counters

1.3.26 show startup-config

Command

```
show startup-config
```

Parameters

show

 Show running system information

startup-config

 Contentes of startup configuration

1.3.27 show stats

Command

```
show stats
```

Parameters

show

 Show running system information

stats

 Show statistical values

1.3.28 show stats level (global|peer|subscriber)

Command

```
show stats level (global|peer|subscriber)
```

Parameters

show

 Show running system information

stats

 Show statistical values

level

 Set the maximum group level

global

 Show global groups only

peer

 Show global and network peer related groups

subscriber

 Show global, peer, and subscriber groups

1.3.29 show subscriber (imsi|msisdn|id|imei) IDENT

Command

```
show subscriber (imsi|msisdn|id|imei) IDENT
```

Parameters

show

 Show running system information

subscriber

 Subscriber management commands

imsi

 Identify subscriber by IMSI

msisdn

 Identify subscriber by MSISDN (phone number)

id

 Identify subscriber by database ID

imei

 Identify subscriber by IMEI

IDENT

 IMSI/MSISDN/ID/IMEI of the subscriber

1.3.30 show talloc-context (application|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

Parameters

show

 Show running system information

talloc-context

 Show talloc memory hierarchy

application

 Application's context

all

 All contexts, if NULL-context tracking is enabled

full

 Display a full talloc memory hierarchy

brief

 Display a brief talloc memory hierarchy

DEPTH

 Specify required maximal depth value

1.3.31 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show

 Show running system information

talloc-context

 Show talloc memory hierarchy

application

 Application's context

all

 All contexts, if NULL-context tracking is enabled

full

 Display a full talloc memory hierarchy

brief

 Display a brief talloc memory hierarchy

DEPTH

 Specify required maximal depth value

filter

 Filter chunks using regular expression

REGEXP

 Regular expression

1.3.32 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

Parameters

show

 Show running system information

talloc-context

 Show talloc memory hierarchy

application

 Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

1.3.33 show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

1.3.34 subscriber (imsi|msisdn|id|imei) IDENT delete

Command

```
subscriber (imsi|msisdn|id|imei) IDENT delete
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

delete

Delete subscriber from database

1.3.35 subscriber (imsi|msisdn|id|imei) IDENT show

Command

```
subscriber (imsi|msisdn|id|imei) IDENT show
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

show

Show subscriber information

1.3.36 subscriber (imsi|msisdn|id|imei) IDENT update aud2g (comp128v1|comp128v2|comp128...

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud2g (comp128v1|comp128v2|comp128v3|xor) ←  
    ki KI
```

Parameters

subscriber

 Subscriber management commands

imsi

 Identify subscriber by IMSI

msisdn

 Identify subscriber by MSISDN (phone number)

id

 Identify subscriber by database ID

imei

 Identify subscriber by IMEI

IDENT

 IMSI/MSISDN/ID/IMEI of the subscriber

update

 Set or update subscriber data

aud2g

 Set 2G authentication data

comp128v1

 Use COMP128v1 algorithm

comp128v2

 Use COMP128v2 algorithm

comp128v3

 Use COMP128v3 algorithm

xor

 Use XOR algorithm

ki

 Set Ki Encryption Key

KI

 Ki as 32 hexadecimal characters

1.3.37 **subscriber (imsi|msisdn|id|imei) IDENT update aud2g none**

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud2g none
```

Parameters

subscriber

 Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

update

Set or update subscriber data

aud2g

Set 2G authentication data

none

Delete 2G authentication data

1.3.38 subscriber (imsi|msisdn|id|imei) IDENT update aud3g milenage k K (op|opc) OP_C [...]

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud3g milenage k K (op|opc) OP_C [ind-↔  
bitlen] [<0-28>]
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

update

Set or update subscriber data

aud3g

Set UMTS authentication data (3G, and 2G with UMTS AKA)

milenage

Use Milenage algorithm

k

Set Encryption Key K

K

K as 32 hexadecimal characters

op

Set OP key

opc

Set OPC key

OP_C

OP or OPC as 32 hexadecimal characters

[ind-bitlen]

Set IND bit length

[<0-28>]

IND bit length value (default: 5)

1.3.39 subscriber (imsi|msisdn|id|imei) IDENT update aud3g none

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud3g none
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

update

Set or update subscriber data

aud3g

Set UMTS authentication data (3G, and 2G with UMTS AKA)

none

Delete 3G authentication data

1.3.40 **subscriber (imsi|msisdn|id|imei) IDENT update imei (none|IMEI)**

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update imei (none|IMEI)
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

update

Set or update subscriber data

imei

Set IMEI of the subscriber (normally populated from MSC, no need to set this manually)

none

Forget IMEI

IMEI

Set IMEI (use for debug only!)

1.3.41 subscriber (imsi|msisdn|id|imei) IDENT update msisdn (none|MSISDN)

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update msisdn (none|MSISDN)
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

update

Set or update subscriber data

msisdn

Set MSISDN (phone number) of the subscriber

none

Remove MSISDN (phone number)

MSISDN

New MSISDN (phone number)

1.3.42 subscriber (imsi|msisdn|id|imei) IDENT update network-access-mode (none|cs|ps|cs+ps)

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update network-access-mode (none|cs|ps|cs+ps)
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

update

Set or update subscriber data

network-access-mode

Set Network Access Mode (NAM) of the subscriber

none

Do not allow access to circuit switched or packet switched services

cs

Allow access to circuit switched services only

ps

Allow access to packet switched services only

cs+ps

Allow access to both circuit and packet switched services

1.3.43 subscriber imsi IDENT create

Command

```
subscriber imsi IDENT create
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

IDENT

IMSI/MSISDN/ID of the subscriber

create

Create subscriber by IMSI

1.3.44 terminal length <0-512>

Command

```
terminal length <0-512>
```

Parameters

terminal

 Set terminal line parameters

length

 Set number of lines on a screen

<0-512>

 Number of lines on screen (0 for no pausing)

1.3.45 terminal monitor

Command

```
terminal monitor
```

Parameters

terminal

 Set terminal line parameters

monitor

 Copy debug output to the current terminal line

1.3.46 terminal no length

Command

```
terminal no length
```

Parameters

terminal

 Set terminal line parameters

no

 Negate a command or set its defaults

length

 Set number of lines on a screen

1.3.47 terminal no monitor

Command

```
terminal no monitor
```

Parameters

terminal

 Set terminal line parameters

no

 Negate a command or set its defaults

monitor

 Copy debug output to the current terminal line

1.3.48 who

Command

```
who
```

Parameters

who

 Display who is on vty

1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

1.4.1 banner motd default

Command

```
banner motd default
```

Parameters

banner

 Set banner string

motd

 Strings for motd

default

 Default string

1.4.2 banner motd file [FILE]

Command

```
banner motd file [FILE]
```

Parameters

banner

 Set banner

motd

 Banner for motd

file

 Banner from a file

[FILE]

 Filename

1.4.3 ctrl

Command

```
ctrl
```

Parameters

ctrl

 Configure the Control Interface

1.4.4 enable password (8|) WORD

Command

```
enable password (8 |) WORD
```

Parameters

enable

 Modify enable password parameters

password

 Assign the privileged level password

8

 Specifies a HIDDEN password will follow

dummy string

WORD

 The HIDDEN 'enable' password string

1.4.5 enable password LINE

Command

```
enable password LINE
```

Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

LINE

The UNENCRYPTED (cleartext) 'enable' password

1.4.6 hlr

Command

```
hlr
```

Parameters

hlr

Configure the HLR

1.4.7 hostname WORD

Command

```
hostname WORD
```

Parameters

hostname

Set system's network name

WORD

This system's network name

1.4.8 line vty

Command

```
line vty
```

Parameters

line

Configure a terminal line

vty

Virtual terminal

1.4.9 log alarms <2-32700>

Command

```
log alarms <2-32700>
```

Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo_strb

<2-32700>

Maximum number of messages to log

1.4.10 log file .FILENAME

Command

```
log file .FILENAME
```

Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

1.4.11 log gsmtap [HOSTNAME]

Command

```
log gsmtap [HOSTNAME]
```

Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

1.4.12 log stderr

Command

```
log stderr
```

Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

1.4.13 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

1.4.14 log syslog local <0-7>

Command

```
log syslog local <0-7>
```

Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

1.4.15 no banner motd

Command

```
no banner motd
```

Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

1.4.16 no enable password

Command

```
no enable password
```

Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

1.4.17 no hostname [HOSTNAME]

Command

```
no hostname [HOSTNAME]
```

Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

1.4.18 no log alarms

Command

```
no log alarms
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo_strb

1.4.19 no log file .FILENAME

Command

```
no log file .FILENAME
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

1.4.20 no log stderr

Command

```
no log stderr
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

1.4.21 no log syslog

Command

```
no log syslog
```

Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

1.4.22 no service advanced-vty

Command

```
no service advanced-vty
```

Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

1.4.23 no service terminal-length [<0-512>]

Command

```
no service terminal-length [<0-512>]
```

Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

1.4.24 no stats reporter log

Command

```
no stats reporter log
```

Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

1.4.25 no stats reporter statsd

Command

```
no stats reporter statsd
```

Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

1.4.26 password (8|) WORD

Command

```
password (8 |) WORD
```

Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

1.4.27 password LINE

Command

```
password LINE
```

Parameters

password

Assign the terminal connection password

LINE

The UNENCRYPTED (cleartext) line password

1.4.28 service advanced-vty

Command

```
service advanced-vty
```

Parameters

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

1.4.29 service terminal-length <0-512>

Command

```
service terminal-length <0-512>
```

Parameters

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

<0-512>

Number of lines of VTY (0 means no line control)

1.4.30 show history

Command

```
show history
```

Parameters

show

Show running system information

history

Display the session command history

1.4.31 stats interval <1-65535>

Command

```
stats interval <1-65535>
```

Parameters

stats

Configure stats sub-system

interval

Set the reporting interval

<1-65535>

Interval in seconds

1.4.32 stats reporter log

Command

```
stats reporter log
```

Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

1.4.33 stats reporter statsd

Command

```
stats reporter statsd
```

Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

1.5.1 logging color (0|1)

Command

```
logging color (0|1)
```

Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

Command

```
logging filter all (0|1)
```

Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

1.5.3 logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...

Command

```
logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ←
    lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ←
    fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

main

Main Program

db

Database Layer

auc

Authentication Center

ss

Supplementary Services

lglobal

Library-internal global log family

llapd

LAPD in libosmogsm

linp

A-bis Input Subsystem

lmux

A-bis B-Subchannel TRAU Frame Multiplex

lmi

A-bis Input Driver for Signalling

lmib

A-bis Input Driver for B-Channels (voice)

lsms

Layer3 Short Message Service (SMS)

lctrl

Control Interface

lgtp

GPRS GTP library

lstats
 Statistics messages and logging

lgsup
 Generic Subscriber Update Protocol

loap
 Osmocom Authentication Protocol

lss7
 libosmo-sigtran Signalling System 7

lsccp
 libosmo-sigtran SCCP Implementation

lsua
 libosmo-sigtran SCCP User Adaptation

lm3ua
 libosmo-sigtran MTP3 User Adaptation

lmgcp
 libosmo-mgcp Media Gateway Control Protocol

ljbuf
 libosmo-netif Jitter Buffer

lrspc
 Remote SIM protocol

debug
 Log debug messages and higher levels

info
 Log informational messages and higher levels

notice
 Log noticeable messages and higher levels

error
 Log error messages and higher levels

fatal
 Log only fatal messages

1.5.4 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

1.5.5 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

1.5.6 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

1.5.7 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

1.5.8 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

1.5.9 logging print file (0|1|basename) [last]

Command

```
logging print file (0|1|basename) [last]
```

Parameters

logging

Configure logging

print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

1.5.10 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

1.5.11 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

1.5.12 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

1.6 config-stats

1.6.1 disable

Command

```
disable
```

Parameters

disable

Disable the reporter

1.6.2 enable

Command

```
enable
```

Parameters

enable

Enable the reporter

1.6.3 level (global|peer|subscriber)

Command

```
level (global|peer|subscriber)
```

Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

1.6.4 local-ip ADDR

Command

```
local-ip ADDR
```

Parameters

local-ip

Set the IP address to which we bind locally

ADDR

IP Address

1.6.5 mtu <100-65535>

Command

```
mtu <100-65535>
```

Parameters

mtu

Set the maximum packet size

<100-65535>

Size in byte

1.6.6 no local-ip

Command

```
no local-ip
```

Parameters

no

Negate a command or set its defaults

local-ip

Set the IP address to which we bind locally

1.6.7 no mtu

Command

```
no mtu
```

Parameters

no

Negate a command or set its defaults

mtu

Set the maximum packet size

1.6.8 no prefix

Command

```
no prefix
```

Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

1.6.9 prefix PREFIX

Command

```
prefix PREFIX
```

Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

1.6.10 remote-ip ADDR

Command

```
remote-ip ADDR
```

Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

1.6.11 remote-port <1-65535>

Command

```
remote-port <1-65535>
```

Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

1.7 config-line

1.7.1 bind A.B.C.D [<0-65535>]

Command

```
bind A.B.C.D [<0-65535>]
```

Parameters

bind

Accept VTY telnet connections on local interface

A.B.C.D

Local interface IP address (default: 127.0.0.1)

[<0-65535>]

Local TCP port number

1.7.2 login

Command

```
login
```

Parameters

login

Enable password checking

1.7.3 no login

Command

```
no login
```

Parameters

no

Negate a command or set its defaults

login

Enable password checking

1.8 config-ctrl

1.8.1 bind A.B.C.D

Command

```
bind A.B.C.D
```

Parameters

bind

Set bind address to listen for Control connections

A.B.C.D

Local IP address (default 127.0.0.1)

1.9 config-hlr

1.9.1 database PATH

Command

```
database PATH
```

Parameters

database

Set the path to the HLR database file

PATH

Relative or absolute file system path to the database file (default is 'hlr.db')

1.9.2 euse NAME

Command

```
euse NAME
```

Parameters

euse

Configure a particular External USSD Entity

NAME

Alphanumeric name of the External USSD Entity

1.9.3 gsup

Command

```
gsup
```

Parameters

gsup

Configure GSUP options

1.9.4 ncss-guard-timeout <0-255>

Command

```
ncss-guard-timeout <0-255>
```

Parameters

ncss-guard-timeout

Set guard timer for NCSS (call independent SS) session activity

<0-255>

Guard timer value (sec.), or 0 to disable

1.9.5 no euse NAME

Command

```
no euse NAME
```

Parameters

no

Negate a command or set its defaults

euse

Remove a particular External USSD Entity

NAME

Alphanumeric name of the External USSD Entity

1.9.6 no store-imei

Command

```
no store-imei
```

Parameters

no

Do not save the IMEI in the database, when receiving Check IMEI requests.

store-imei

(null)

1.9.7 no subscriber-create-on-demand

Command

```
no subscriber-create-on-demand
```

Parameters

no

Do not make a new record when a subscriber is first seen.

subscriber-create-on-demand

(null)

1.9.8 no ussd default-route

Command

```
no ussd default-route
```

Parameters

no

Negate a command or set its defaults

ussd

USSD Configuration

default-route

Remove the default-route for all USSD to unknown destinations

1.9.9 no ussd route prefix PREFIX

Command

```
no ussd route prefix PREFIX
```

Parameters

no

Negate a command or set its defaults

ussd

USSD Configuration

route

Routing Configuration

prefix

Prefix-Matching Route

PREFIX

USSD Prefix

1.9.10 store-imei

Command

```
store-imei
```

Parameters

store-imei

Save the IMEI in the database when receiving Check IMEI requests. Note that an MSC does not necessarily send Check IMEI requests (for OsmoMSC, you may want to set 'check-imei-rqd 1').

1.9.11 subscriber-create-on-demand (no-msisdn|<3-15>) (none|cs|ps|cs+ps)

Command

```
subscriber-create-on-demand (no-msisdn|<3-15>) (none|cs|ps|cs+ps)
```

Parameters

subscriber-create-on-demand

Make a new record when a subscriber is first seen.

no-msisdn

Do not automatically assign MSISDN.

<3-15>

Length of an automatically assigned MSISDN.

none

Do not allow any NAM (Network Access Mode) by default.

cs

Allow access to circuit switched NAM by default.

ps

Allow access to packet switched NAM by default.

cs+ps

Allow access to circuit and packet switched NAM by default.

1.9.12 ussd default-route external EUSE

Command

```
ussd default-route external EUSE
```

Parameters

ussd

USSD Configuration

default-route

Configure default-route for all USSD to unknown destinations

external

External USSD Handler

EUSE

Name of External USSD Handler (IPA CCM ID)

1.9.13 ussd route prefix PREFIX external EUSE

Command

```
ussd route prefix PREFIX external EUSE
```

Parameters

ussd

USSD Configuration

route

 Routing Configuration

prefix

 Prefix-Matching Route

PREFIX

 USSD Prefix

external

 External USSD Handler

EUSE

 Name of External USSD Handler (IPA CCM ID)

1.9.14 ussd route prefix PREFIX internal (own-msisdn|own-imsi)

Command

```
ussd route prefix PREFIX internal (own-msisdn|own-imsi)
```

Parameters

ussd

 USSD Configuration

route

 Routing Configuration

prefix

 Prefix-Matching Route

PREFIX

 USSD Prefix

internal

 Internal USSD Handler

own-msisdn

 Respond with subscribers' own MSISDN

own-imsi

 Respond with subscribers' own IMSI

1.10 config-hlr-gsup

1.10.1 bind ip A.B.C.D

Command

```
bind ip A.B.C.D
```

Parameters

bind

Listen/Bind related socket option

ip

IP information

A.B.C.D

IPv4 Address to bind the GSUP interface to

1.11 config-hlr-euse