

# **OsmoHLR VTY Reference**

Copyright © 2017

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

**COLLABORATORS**

	<i>TITLE :</i> OsmoHLR VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		January 8, 2021	

**REVISION HISTORY**

NUMBER	DATE	DESCRIPTION	NAME
v1	18th September 2017	Initial	nh

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list	2
1.1.5	show running-config	3
1.1.6	write	3
1.1.7	write file	3
1.1.8	write memory	3
1.1.9	write terminal	4
1.2	view	4
1.2.1	enable	4
1.2.2	logging color (0 1)	4
1.2.3	logging disable	5
1.2.4	logging enable	5
1.2.5	logging filter all (0 1)	5
1.2.6	logging level (main db auc ss lg lobal lapd linp lmux lmil mibl sms lctrl lgtpl ...	6
1.2.7	logging level force-all (debug info notice error fatal)	7
1.2.8	logging level set-all (debug info notice error fatal)	8
1.2.9	logging print category (0 1)	9
1.2.10	logging print category-hex (0 1)	9
1.2.11	logging print extended-timestamp (0 1)	10
1.2.12	logging print file (0 1 basename) [last]	10
1.2.13	logging print level (0 1)	11
1.2.14	logging set-log-mask MASK	11
1.2.15	logging timestamp (0 1)	11
1.2.16	no logging level force-all	12
1.2.17	show alarms	12
1.2.18	show asciidoc counters	13

1.2.19	show gsup-connections . . . . .	13
1.2.20	show history . . . . .	13
1.2.21	show logging vty . . . . .	14
1.2.22	show online-help . . . . .	14
1.2.23	show rate-counters . . . . .	14
1.2.24	show stats . . . . .	15
1.2.25	show stats level (global peer subscriber) . . . . .	15
1.2.26	show subscriber (ims imsdn lmei) IDENT . . . . .	15
1.2.27	show talloc-context (application all) (full brief DEPTH) . . . . .	16
1.2.28	show talloc-context (application all) (full brief DEPTH) filter REGEXP . . . . .	17
1.2.29	show talloc-context (application all) (full brief DEPTH) tree ADDRESS . . . . .	17
1.2.30	show version . . . . .	18
1.2.31	subscriber (ims imsdn lmei) IDENT show . . . . .	18
1.2.32	terminal length <0-512> . . . . .	19
1.2.33	terminal no length . . . . .	19
1.2.34	who . . . . .	19
1.3	enable . . . . .	19
1.3.1	configure terminal . . . . .	20
1.3.2	copy running-config startup-config . . . . .	20
1.3.3	disable . . . . .	20
1.3.4	logging color (0 1) . . . . .	21
1.3.5	logging disable . . . . .	21
1.3.6	logging enable . . . . .	21
1.3.7	logging filter all (0 1) . . . . .	22
1.3.8	logging level (main db auc ss lg global lapd linp lmux lmi lmb lsm lctrl lgtpl... . . . .	22
1.3.9	logging level force-all (debug info notice error fatal) . . . . .	24
1.3.10	logging level set-all (debug info notice error fatal) . . . . .	25
1.3.11	logging print category (0 1) . . . . .	25
1.3.12	logging print category-hex (0 1) . . . . .	26
1.3.13	logging print extended-timestamp (0 1) . . . . .	26
1.3.14	logging print file (0 1 basename) [last] . . . . .	27
1.3.15	logging print level (0 1) . . . . .	27
1.3.16	logging set-log-mask MASK . . . . .	28
1.3.17	logging timestamp (0 1) . . . . .	28
1.3.18	no logging level force-all . . . . .	28
1.3.19	show alarms . . . . .	29
1.3.20	show asciidoc counters . . . . .	29
1.3.21	show gsup-connections . . . . .	29
1.3.22	show history . . . . .	30

1.3.23	show logging vty . . . . .	30
1.3.24	show online-help . . . . .	30
1.3.25	show rate-counters . . . . .	31
1.3.26	show startup-config . . . . .	31
1.3.27	show stats . . . . .	31
1.3.28	show stats level (global peer subscriber) . . . . .	32
1.3.29	show subscriber (imsilmsisdn limei) IDENT . . . . .	32
1.3.30	show talloc-context (application all) (full brief DEPTH) . . . . .	33
1.3.31	show talloc-context (application all) (full brief DEPTH) filter REGEXP . . . . .	33
1.3.32	show talloc-context (application all) (full brief DEPTH) tree ADDRESS . . . . .	34
1.3.33	show version . . . . .	34
1.3.34	subscriber (imsilmsisdn limei) IDENT delete . . . . .	35
1.3.35	subscriber (imsilmsisdn limei) IDENT show . . . . .	35
1.3.36	subscriber (imsilmsisdn limei) IDENT update aud2g (comp128v1 comp128v2 comp128... . . . .	36
1.3.37	subscriber (imsilmsisdn limei) IDENT update aud2g none . . . . .	37
1.3.38	subscriber (imsilmsisdn limei) IDENT update aud3g milenage k K (op opc) OP_C [... . . . .	37
1.3.39	subscriber (imsilmsisdn limei) IDENT update aud3g none . . . . .	38
1.3.40	subscriber (imsilmsisdn limei) IDENT update imei (none IMEI) . . . . .	39
1.3.41	subscriber (imsilmsisdn limei) IDENT update msisdn (none MSISDN) . . . . .	40
1.3.42	subscriber (imsilmsisdn limei) IDENT update network-access-mode (none cs ps cs... . . . .	40
1.3.43	subscriber imsi IDENT create . . . . .	41
1.3.44	terminal length <0-512> . . . . .	42
1.3.45	terminal monitor . . . . .	42
1.3.46	terminal no length . . . . .	42
1.3.47	terminal no monitor . . . . .	43
1.3.48	who . . . . .	43
1.4	config . . . . .	43
1.4.1	banner motd default . . . . .	43
1.4.2	banner motd file [FILE] . . . . .	44
1.4.3	ctrl . . . . .	44
1.4.4	enable password (8 ) WORD . . . . .	44
1.4.5	enable password LINE . . . . .	45
1.4.6	hlr . . . . .	45
1.4.7	hostname WORD . . . . .	45
1.4.8	line vty . . . . .	45
1.4.9	log alarms <2-32700> . . . . .	46
1.4.10	log file .FILENAME . . . . .	46
1.4.11	log gsmtap [HOSTNAME] . . . . .	46
1.4.12	log stderr . . . . .	47

1.4.13	log syslog (authpriv cron daemon ftp lpr mail news user uucp) . . . . .	47
1.4.14	log syslog local <0-7> . . . . .	48
1.4.15	no banner motd . . . . .	48
1.4.16	no enable password . . . . .	48
1.4.17	no hostname [HOSTNAME] . . . . .	49
1.4.18	no log alarms . . . . .	49
1.4.19	no log file .FILENAME . . . . .	49
1.4.20	no log stderr . . . . .	50
1.4.21	no log syslog . . . . .	50
1.4.22	no service advanced-vty . . . . .	50
1.4.23	no service terminal-length [<0-512>] . . . . .	51
1.4.24	no stats reporter log . . . . .	51
1.4.25	no stats reporter statsd . . . . .	51
1.4.26	password (8l) WORD . . . . .	52
1.4.27	password LINE . . . . .	52
1.4.28	service advanced-vty . . . . .	52
1.4.29	service terminal-length <0-512> . . . . .	53
1.4.30	show history . . . . .	53
1.4.31	stats interval <1-65535> . . . . .	53
1.4.32	stats reporter log . . . . .	54
1.4.33	stats reporter statsd . . . . .	54
1.5	config-log . . . . .	54
1.5.1	logging color (0l1) . . . . .	54
1.5.2	logging filter all (0l1) . . . . .	55
1.5.3	logging level (main db auc ss l global ll lapd linp lmux lmi l mib l sms l ctr ll gtp l ... . . . .	55
1.5.4	logging level force-all (debug info notice error fatal) . . . . .	57
1.5.5	logging level set-all (debug info notice error fatal) . . . . .	58
1.5.6	logging print category (0l1) . . . . .	58
1.5.7	logging print category-hex (0l1) . . . . .	59
1.5.8	logging print extended-timestamp (0l1) . . . . .	59
1.5.9	logging print file (0l1 basename) [last] . . . . .	60
1.5.10	logging print level (0l1) . . . . .	60
1.5.11	logging timestamp (0l1) . . . . .	61
1.5.12	no logging level force-all . . . . .	61
1.6	config-stats . . . . .	61
1.6.1	disable . . . . .	61
1.6.2	enable . . . . .	62
1.6.3	level (global peer subscriber) . . . . .	62
1.6.4	local-ip ADDR . . . . .	62

1.6.5	mtu <100-65535>	63
1.6.6	no local-ip	63
1.6.7	no mtu	63
1.6.8	no prefix	63
1.6.9	prefix PREFIX	64
1.6.10	remote-ip ADDR	64
1.6.11	remote-port <1-65535>	64
1.7	config-line	65
1.7.1	bind A.B.C.D [<0-65535>]	65
1.7.2	login	65
1.7.3	no login	65
1.8	config-ctrl	66
1.8.1	bind A.B.C.D	66
1.9	config-hlr	66
1.9.1	database PATH	66
1.9.2	euse NAME	66
1.9.3	gsup	67
1.9.4	ncss-guard-timeout <0-255>	67
1.9.5	no euse NAME	67
1.9.6	no store-imei	67
1.9.7	no subscriber-create-on-demand	68
1.9.8	no ussd default-route	68
1.9.9	no ussd route prefix PREFIX	68
1.9.10	store-imei	69
1.9.11	subscriber-create-on-demand (no-msisdn<3-15>) (none cs ps cs+ps)	69
1.9.12	ussd default-route external EUSE	69
1.9.13	ussd route prefix PREFIX external EUSE	70
1.9.14	ussd route prefix PREFIX internal (own-msisdn own-imsi)	70
1.10	config-hlr-gsup	71
1.10.1	bind ip A.B.C.D	71
1.11	config-hlr-euse	71



# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

## Chapter 1

# VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sysmocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

### 1.1.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.4 list

#### Command

```
list
```

#### Parameters

list

Print command list

### 1.1.5 show running-config

#### Command

```
show running-config
```

#### Parameters

##### show

Show running system information

##### running-config

running configuration

### 1.1.6 write

#### Command

```
write
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

### 1.1.7 write file

#### Command

```
write file
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### file

Write to configuration file

### 1.1.8 write memory

#### Command

```
write memory
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### memory

Write configuration to the file (same as write file)

---

### 1.1.9 write terminal

#### Command

```
write terminal
```

#### Parameters

##### write

Write running configuration to memory, network, or terminal

##### terminal

Write to terminal

## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 enable

#### Command

```
enable
```

#### Parameters

##### enable

Turn on privileged mode command

### 1.2.2 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

##### 0

Don't use color for printing messages

##### 1

Use color for printing messages

---

### 1.2.3 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

### 1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

---

## 1.2.6 logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...

### Command

```
logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵  
             lgsup|loap|lss7|lscdp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ↵  
             fatal)
```

### Parameters

#### logging

Configure logging

#### level

Set the log level for a specified category

#### main

Main Program

#### db

Database Layer

#### auc

Authentication Center

#### ss

Supplementary Services

#### lglobal

Library-internal global log family

#### llapd

LAPD in libosmogsm

#### linp

A-bis Input Subsystem

#### lmux

A-bis B-Subchannel TRAU Frame Multiplex

#### lmi

A-bis Input Driver for Signalling

#### lmib

A-bis Input Driver for B-Channels (voice)

#### lsms

Layer3 Short Message Service (SMS)

#### lctrl

Control Interface

#### lgtp

GPRS GTP library

lstats

Statistics messages and logging

lgsup

Generic Subscriber Update Protocol

loap

Osmocom Authentication Protocol

lss7

libosmo-sigtran Signalling System 7

lsccp

libosmo-sigtran SCCP Implementation

lsua

libosmo-sigtran SCCP User Adaptation

lm3ua

libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljibuf

libosmo-netif Jitter Buffer

lrspro

Remote SIM protocol

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.7 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging



**level**

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

## 1.2.8 logging level set-all (debug|info|notice|error|fatal)

**Command**

```
logging level set-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**set-all**

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

---

### 1.2.9 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.2.10 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.2.11 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.12 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.13 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the log level name

### 1.2.14 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.15 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

### logging

Configure logging

### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

## 1.2.16 no logging level force-all

### Command

```
no logging level force-all
```

### Parameters

no

Negate a command or set its defaults

### logging

Configure logging

### level

Set the log level for a specified category

### force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.2.17 show alarms

### Command

```
show alarms
```

### Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.2.18 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

##### show

Show running system information

##### asciidoc

Asciidoc generation

##### counters

Generate table of all registered counters

### 1.2.19 show gsup-connections

#### Command

```
show gsup-connections
```

#### Parameters

##### show

Show running system information

##### gsup-connections

GSUP Connections from VLRs, SGSNs, EUSEs

### 1.2.20 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.2.21 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vtty

Show current logging configuration for this vty

### 1.2.22 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.2.23 show rate-counters

#### Command

```
show rate-counters
```

#### Parameters

##### show

Show running system information

##### rate-counters

Show all rate counters

### 1.2.24 show stats

#### Command

```
show stats
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

### 1.2.25 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### level

Set the maximum group level

##### global

Show global groups only

##### peer

Show global and network peer related groups

##### subscriber

Show global, peer, and subscriber groups

### 1.2.26 show subscriber (imsi|msisdn|id|imei) IDENT

#### Command

```
show subscriber (imsi|msisdn|id|imei) IDENT
```

#### Parameters

##### show

Show running system information

---



## subscriber

Subscriber management commands

## imsi

Identify subscriber by IMSI

## msisdn

Identify subscriber by MSISDN (phone number)

## id

Identify subscriber by database ID

## imei

Identify subscriber by IMEI

## IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

### 1.2.27 show talloc-context (application|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

### 1.2.28 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### all

All contexts, if NULL-context tracking is enabled

##### full

Display a full talloc memory hierarchy

##### brief

Display a brief talloc memory hierarchy

##### DEPTH

Specify required maximal depth value

##### filter

Filter chunks using regular expression

##### REGEXP

Regular expression

### 1.2.29 show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

##### show

Show running system information

##### talloc-context

Show talloc memory hierarchy

##### application

Application's context

##### all

All contexts, if NULL-context tracking is enabled

---

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.2.30 show version

Command

```
show version
```

Parameters

show

Show running system information

version

Displays program version

### 1.2.31 subscriber (imsi|msisdn|id|imei) IDENT show

Command

```
subscriber (imsi|msisdn|id|imei) IDENT show
```

Parameters

subscriber

Subscriber management commands

imsi

Identify subscriber by IMSI

msisdn

Identify subscriber by MSISDN (phone number)

id

Identify subscriber by database ID

imei

Identify subscriber by IMEI

IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

show

Show subscriber information

### 1.2.32 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.2.33 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.2.34 who

#### Command

```
who
```

#### Parameters

##### who

Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

---

### 1.3.1 configure terminal

#### Command

```
configure terminal
```

#### Parameters

##### configure

Configuration from vty interface

##### terminal

Configuration terminal

### 1.3.2 copy running-config startup-config

#### Command

```
copy running-config startup-config
```

#### Parameters

##### copy

Copy configuration

##### running-config

Copy running config to...

##### startup-config

Copy running config to startup config (same as write file)

### 1.3.3 disable

#### Command

```
disable
```

#### Parameters

##### disable

Turn off privileged mode command

### 1.3.4 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.3.5 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.3.6 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

---

### 1.3.7 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.3.8 logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...

#### Command

```
logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵  
lgsup|loap|lss7|lscdp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ↵  
fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### main

Main Program

##### db

Database Layer

##### auc

Authentication Center

ss

Supplementary Services

lglobal

Library-internal global log family

llapd

LAPD in libosmogsm

linp

A-bis Input Subsystem

lmux

A-bis B-Subchannel TRAU Frame Multiplex

lmi

A-bis Input Driver for Signalling

lmib

A-bis Input Driver for B-Channels (voice)

lsms

Layer3 Short Message Service (SMS)

lctrl

Control Interface

lgtp

GPRS GTP library

lstats

Statistics messages and logging

lgsup

Generic Subscriber Update Protocol

loap

Osmocom Authentication Protocol

lss7

libosmo-sigtran Signalling System 7

lsccp

libosmo-sigtran SCCP Implementation

lsua

libosmo-sigtran SCCP User Adaptation

lm3ua

libosmo-sigtran MTP3 User Adaptation

lmgcp

libosmo-mgcp Media Gateway Control Protocol

ljibuf

libosmo-netif Jitter Buffer



lrspro

Remote SIM protocol

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.9 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.10 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.3.11 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with category/subsystem name

---

### 1.3.12 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.3.13 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.14 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.15 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the log level name

### 1.3.16 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.17 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

##### 0

Don't prefix each log message

##### 1

Prefix each log message with current timestamp

### 1.3.18 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

##### no

Negate a command or set its defaults

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.19 show alarms

#### Command

```
show alarms
```

#### Parameters

##### show

Show running system information

##### alarms

Show current logging configuration

### 1.3.20 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

##### show

Show running system information

##### asciidoc

Asciidoc generation

##### counters

Generate table of all registered counters

### 1.3.21 show gsup-connections

#### Command

```
show gsup-connections
```

#### Parameters

##### show

Show running system information

##### gsup-connections

GSUP Connections from VLRs, SGSNs, EUSEs

### 1.3.22 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.3.23 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vty

Show current logging configuration for this vty

### 1.3.24 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.3.25 show rate-counters

#### Command

```
show rate-counters
```

#### Parameters

##### show

Show running system information

##### rate-counters

Show all rate counters

### 1.3.26 show startup-config

#### Command

```
show startup-config
```

#### Parameters

##### show

Show running system information

##### startup-config

Contentes of startup configuration

### 1.3.27 show stats

#### Command

```
show stats
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values



### 1.3.28 show stats level (global|peer|subscriber)

#### Command

```
show stats level (global|peer|subscriber)
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### level

Set the maximum group level

##### global

Show global groups only

##### peer

Show global and network peer related groups

##### subscriber

Show global, peer, and subscriber groups

### 1.3.29 show subscriber (imsi|msisdn|id|imei) IDENT

#### Command

```
show subscriber (imsi|msisdn|id|imei) IDENT
```

#### Parameters

##### show

Show running system information

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

---

### 1.3.30 show talloc-context (application|all) (full|brief|DEPTH)

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH)
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

### 1.3.31 show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP

#### Command

```
show talloc-context (application|all) (full|brief|DEPTH) filter REGEXP
```

#### Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

**DEPTH**

Specify required maximal depth value

**filter**

Filter chunks using regular expression

**REGEXP**

Regular expression

### 1.3.32 **show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS**

**Command**

```
show talloc-context (application|all) (full|brief|DEPTH) tree ADDRESS
```

**Parameters****show**

Show running system information

**talloc-context**

Show talloc memory hierarchy

**application**

Application's context

**all**

All contexts, if NULL-context tracking is enabled

**full**

Display a full talloc memory hierarchy

**brief**

Display a brief talloc memory hierarchy

**DEPTH**

Specify required maximal depth value

**tree**

Display only a specific memory chunk

**ADDRESS**

Chunk address (e.g. 0xdeadbeef)

### 1.3.33 **show version**

**Command**

```
show version
```

**Parameters****show**

Show running system information

**version**

Displays program version

### 1.3.34 subscriber (imsi|msisdn|id|imei) IDENT delete

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT delete
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

##### delete

Delete subscriber from database

### 1.3.35 subscriber (imsi|msisdn|id|imei) IDENT show

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT show
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

##### show

Show subscriber information

---

### 1.3.36 subscriber (imsi|msisdn|id|imei) IDENT update aud2g (comp128v1|comp128v2|comp128...

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud2g (comp128v1|comp128v2|comp128v3|xor) ↔  
ki KI
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

##### update

Set or update subscriber data

##### aud2g

Set 2G authentication data

##### comp128v1

Use COMP128v1 algorithm

##### comp128v2

Use COMP128v2 algorithm

##### comp128v3

Use COMP128v3 algorithm

##### xor

Use XOR algorithm

##### ki

Set Ki Encryption Key

##### KI

Ki as 32 hexadecimal characters

### 1.3.37 subscriber (imsi|msisdn|id|imei) IDENT update aud2g none

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud2g none
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

##### update

Set or update subscriber data

##### aud2g

Set 2G authentication data

##### none

Delete 2G authentication data

### 1.3.38 subscriber (imsi|msisdn|id|imei) IDENT update aud3g milenage k K (op|opc) OP\_C [...

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud3g milenage k K (op|opc) OP_C [ind- ↵  
bitlen] [<0-28>]
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

**id**  
Identify subscriber by database ID

**imei**  
Identify subscriber by IMEI

**IDENT**  
IMSI/MSISDN/ID/IMEI of the subscriber

**update**  
Set or update subscriber data

**aud3g**  
Set UMTS authentication data (3G, and 2G with UMTS AKA)

**milenage**  
Use Milenage algorithm

**k**  
Set Encryption Key K

**K**  
K as 32 hexadecimal characters

**op**  
Set OP key

**opc**  
Set OPC key

**OP\_C**  
OP or OPC as 32 hexadecimal characters

**[ind-bitlen]**  
Set IND bit length

**[<0-28>]**  
IND bit length value (default: 5)

### 1.3.39 subscriber (imsi|msisdn|id|imei) IDENT update aud3g none

Command

```
subscriber (imsi|msisdn|id|imei) IDENT update aud3g none
```

Parameters

**subscriber**  
Subscriber management commands

**imsi**  
Identify subscriber by IMSI

**msisdn**  
Identify subscriber by MSISDN (phone number)

id  
Identify subscriber by database ID

imei  
Identify subscriber by IMEI

IDENT  
IMSI/MSISDN/ID/IMEI of the subscriber

update  
Set or update subscriber data

aud3g  
Set UMTS authentication data (3G, and 2G with UMTS AKA)

none  
Delete 3G authentication data

### 1.3.40 subscriber (imsi|msisdn|id|imei) IDENT update imei (none|IMEI)

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update imei (none|IMEI)
```

#### Parameters

subscriber  
Subscriber management commands

imsi  
Identify subscriber by IMSI

msisdn  
Identify subscriber by MSISDN (phone number)

id  
Identify subscriber by database ID

imei  
Identify subscriber by IMEI

IDENT  
IMSI/MSISDN/ID/IMEI of the subscriber

update  
Set or update subscriber data

imei  
Set IMEI of the subscriber (normally populated from MSC, no need to set this manually)

none  
Forget IMEI

IMEI  
Set IMEI (use for debug only!)

---



### 1.3.41 subscriber (imsi|msisdn|id|imei) IDENT update msisdn (none|MSISDN)

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update msisdn (none|MSISDN)
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

##### id

Identify subscriber by database ID

##### imei

Identify subscriber by IMEI

##### IDENT

IMSI/MSISDN/ID/IMEI of the subscriber

##### update

Set or update subscriber data

##### msisdn

Set MSISDN (phone number) of the subscriber

##### none

Remove MSISDN (phone number)

##### MSISDN

New MSISDN (phone number)

### 1.3.42 subscriber (imsi|msisdn|id|imei) IDENT update network-access-mode (none|cs|ps|cs...

#### Command

```
subscriber (imsi|msisdn|id|imei) IDENT update network-access-mode (none|cs|ps|cs+ps)
```

#### Parameters

##### subscriber

Subscriber management commands

##### imsi

Identify subscriber by IMSI

##### msisdn

Identify subscriber by MSISDN (phone number)

id	Identify subscriber by database ID
imei	Identify subscriber by IMEI
IDENT	IMSI/MSISDN/ID/IMEI of the subscriber
update	Set or update subscriber data
network-access-mode	Set Network Access Mode (NAM) of the subscriber
none	Do not allow access to circuit switched or packet switched services
cs	Allow access to circuit switched services only
ps	Allow access to packet switched services only
cs+ps	Allow access to both circuit and packet switched services

### 1.3.43 subscriber imsi IDENT create

#### Command

```
subscriber imsi IDENT create
```

#### Parameters

subscriber	Subscriber management commands
imsi	Identify subscriber by IMSI
IDENT	IMSI/MSISDN/ID of the subscriber
create	Create subscriber by IMSI

### 1.3.44 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.3.45 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

### 1.3.46 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.3.47 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

### 1.3.48 who

#### Command

```
who
```

#### Parameters

##### who

Display who is on vty

## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

##### banner

Set banner string

##### motd

Strings for motd

##### default

Default string

---

### 1.4.2 banner motd file [FILE]

#### Command

```
banner motd file [FILE]
```

#### Parameters

##### banner

Set banner

##### motd

Banner for motd

##### file

Banner from a file

##### [FILE]

Filename

### 1.4.3 ctrl

#### Command

```
ctrl
```

#### Parameters

##### ctrl

Configure the Control Interface

### 1.4.4 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### 8

Specifies a HIDDEN password will follow

##### dummy string

##### WORD

The HIDDEN 'enable' password string

### 1.4.5 enable password LINE

#### Command

```
enable password LINE
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.4.6 hlr

#### Command

```
hlr
```

#### Parameters

##### hlr

Configure the HLR

### 1.4.7 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

### 1.4.8 line vty

#### Command

```
line vty
```

#### Parameters

##### line

Configure a terminal line

##### vty

Virtual terminal

---

### 1.4.9 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

<2-32700>

Maximum number of messages to log

### 1.4.10 log file .FILENAME

#### Command

```
log file .FILENAME
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.11 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

---

### 1.4.12 log stderr

#### Command

```
log stderr
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.13 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

---



### 1.4.14 log syslog local <0-7>

#### Command

```
log syslog local <0-7>
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

### 1.4.15 no banner motd

#### Command

```
no banner motd
```

#### Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

### 1.4.16 no enable password

#### Command

```
no enable password
```

#### Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

---

### 1.4.17 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.4.18 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.4.19 no log file .FILENAME

#### Command

```
no log file .FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

.FILENAME

Filename

### 1.4.20 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.21 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.4.22 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

---

### 1.4.23 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

### 1.4.24 no stats reporter log

#### Command

```
no stats reporter log
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.25 no stats reporter statsd

#### Command

```
no stats reporter statsd
```

#### Parameters

no

Negate a command or set its defaults

---

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

### 1.4.26 password (8|) WORD

Command

```
password (8|) WORD
```

Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

### 1.4.27 password LINE

Command

```
password LINE
```

Parameters

password

Assign the terminal connection password

LINE

The UNENCRYPTED (cleartext) line password

### 1.4.28 service advanced-vty

Command

```
service advanced-vty
```

Parameters

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.29 service terminal-length <0-512>

#### Command

```
service terminal-length <0-512>
```

#### Parameters

##### service

Set up miscellaneous service

##### terminal-length

System wide terminal length configuration

##### <0-512>

Number of lines of VTY (0 means no line control)

### 1.4.30 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.4.31 stats interval <1-65535>

#### Command

```
stats interval <1-65535>
```

#### Parameters

##### stats

Configure stats sub-system

##### interval

Set the reporting interval

##### <1-65535>

Interval in seconds

---

### 1.4.32 stats reporter log

#### Command

```
stats reporter log
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

### 1.4.33 stats reporter statsd

#### Command

```
stats reporter statsd
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

**logging**

Configure logging

**color**

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

**1.5.2 logging filter all (0|1)**

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

**Command**

```
logging filter all (0|1)
```

**Parameters****logging**

Configure logging

**filter**

Filter log messages

**all**

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

**1.5.3 logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|l...****Command**

```
logging level (main|db|auc|ss|lglobal|llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats| ↵
             lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf|lrspro) (debug|info|notice|error| ↵
             fatal)
```

**Parameters****logging**

Configure logging



## level

Set the log level for a specified category

## main

Main Program

## db

Database Layer

## auc

Authentication Center

## ss

Supplementary Services

## lglobal

Library-internal global log family

## llapd

LAPD in libosmogsm

## linp

A-bis Input Subsystem

## lmux

A-bis B-Subchannel TRAU Frame Multiplex

## lmi

A-bis Input Driver for Signalling

## lmib

A-bis Input Driver for B-Channels (voice)

## lsms

Layer3 Short Message Service (SMS)

## lctrl

Control Interface

## lgtp

GPRS GTP library

## lstats

Statistics messages and logging

## lgsup

Generic Subscriber Update Protocol

## loap

Osmocom Authentication Protocol

## lss7

libosmo-sigtran Signalling System 7

## lsccp

libosmo-sigtran SCCP Implementation

---

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

#### 1.5.4 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.5.5 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.5.6 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print  
    Log output settings

category  
    Configure log message

0  
    Don't prefix each log message

1  
    Prefix each log message with category/subsystem name

### 1.5.7 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging  
    Configure logging

print  
    Log output settings

category-hex  
    Configure log message

0  
    Don't prefix each log message

1  
    Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.8 logging print extended-timestamp (0|1)

Command

```
logging print extended-timestamp (0|1)
```

Parameters

logging  
    Configure logging

print  
    Log output settings

extended-timestamp  
    Configure log message timestamping

0  
    Don't prefix each log message

1  
    Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.5.9 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.10 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

##### 0

Don't prefix each log message

##### 1

Prefix each log message with the log level name

### 1.5.11 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.5.12 no logging level force-all

#### Command

```
no logging level force-all
```

#### Parameters

no

Negate a command or set its defaults

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

#### Command

```
disable
```

#### Parameters

##### disable

Disable the reporter

---

### 1.6.2 enable

#### Command

```
enable
```

#### Parameters

##### enable

Enable the reporter

### 1.6.3 level (global|peer|subscriber)

#### Command

```
level (global|peer|subscriber)
```

#### Parameters

##### level

Set the maximum group level

##### global

Report global groups only

##### peer

Report global and network peer related groups

##### subscriber

Report global, peer, and subscriber groups

### 1.6.4 local-ip ADDR

#### Command

```
local-ip ADDR
```

#### Parameters

##### local-ip

Set the IP address to which we bind locally

##### ADDR

IP Address

---

### 1.6.5 mtu <100-65535>

#### Command

```
mtu <100-65535>
```

#### Parameters

mtu

Set the maximum packet size

<100-65535>

Size in byte

### 1.6.6 no local-ip

#### Command

```
no local-ip
```

#### Parameters

no

Negate a command or set its defaults

local-ip

Set the IP address to which we bind locally

### 1.6.7 no mtu

#### Command

```
no mtu
```

#### Parameters

no

Negate a command or set its defaults

mtu

Set the maximum packet size

### 1.6.8 no prefix

#### Command

```
no prefix
```

#### Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

---



### 1.6.9 prefix PREFIX

#### Command

```
prefix PREFIX
```

#### Parameters

##### prefix

Set the item name prefix

##### PREFIX

The prefix string

### 1.6.10 remote-ip ADDR

#### Command

```
remote-ip ADDR
```

#### Parameters

##### remote-ip

Set the remote IP address to which we connect

##### ADDR

IP Address

### 1.6.11 remote-port <1-65535>

#### Command

```
remote-port <1-65535>
```

#### Parameters

##### remote-port

Set the remote port to which we connect

##### <1-65535>

Remote port number

## 1.7 config-line

### 1.7.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

bind

Accept VTY telnet connections on local interface

A.B.C.D

Local interface IP address (default: 127.0.0.1)

[<0-65535>]

Local TCP port number

### 1.7.2 login

#### Command

```
login
```

#### Parameters

login

Enable password checking

### 1.7.3 no login

#### Command

```
no login
```

#### Parameters

no

Negate a command or set its defaults

login

Enable password checking

## 1.8 config-ctrl

### 1.8.1 bind A.B.C.D

Command

```
bind A.B.C.D
```

Parameters

bind

Set bind address to listen for Control connections

A.B.C.D

Local IP address (default 127.0.0.1)

## 1.9 config-hlr

### 1.9.1 database PATH

Command

```
database PATH
```

Parameters

database

Set the path to the HLR database file

PATH

Relative or absolute file system path to the database file (default is 'hlr.db')

### 1.9.2 euse NAME

Command

```
euse NAME
```

Parameters

euse

Configure a particular External USSD Entity

NAME

Alphanumeric name of the External USSD Entity

### 1.9.3 gsup

#### Command

```
gsup
```

#### Parameters

gsup

Configure GSUP options

### 1.9.4 ncss-guard-timeout <0-255>

#### Command

```
ncss-guard-timeout <0-255>
```

#### Parameters

ncss-guard-timeout

Set guard timer for NCSS (call independent SS) session activity

<0-255>

Guard timer value (sec.), or 0 to disable

### 1.9.5 no euse NAME

#### Command

```
no euse NAME
```

#### Parameters

no

Negate a command or set its defaults

euse

Remove a particular External USSD Entity

NAME

Alphanumeric name of the External USSD Entity

### 1.9.6 no store-imei

#### Command

```
no store-imei
```

#### Parameters

no

Do not save the IMEI in the database, when receiving Check IMEI requests.

store-imei

(null)

---

### 1.9.7 no subscriber-create-on-demand

#### Command

```
no subscriber-create-on-demand
```

#### Parameters

no

Do not make a new record when a subscriber is first seen.

subscriber-create-on-demand

(null)

### 1.9.8 no ussd default-route

#### Command

```
no ussd default-route
```

#### Parameters

no

Negate a command or set its defaults

ussd

USSD Configuration

default-route

Remove the default-route for all USSD to unknown destinations

### 1.9.9 no ussd route prefix PREFIX

#### Command

```
no ussd route prefix PREFIX
```

#### Parameters

no

Negate a command or set its defaults

ussd

USSD Configuration

route

Routing Configuration

prefix

Prefix-Matching Route

PREFIX

USSD Prefix

---

### 1.9.10 store-imei

#### Command

```
store-imei
```

#### Parameters

##### store-imei

Save the IMEI in the database when receiving Check IMEI requests. Note that an MSC does not necessarily send Check IMEI requests (for OsmoMSC, you may want to set 'check-imei-rqd 1').

### 1.9.11 subscriber-create-on-demand (no-msisdn|<3-15>) (none|cs|ps|cs+ps)

#### Command

```
subscriber-create-on-demand (no-msisdn|<3-15>) (none|cs|ps|cs+ps)
```

#### Parameters

##### subscriber-create-on-demand

Make a new record when a subscriber is first seen.

##### no-msisdn

Do not automatically assign MSISDN.

##### <3-15>

Length of an automatically assigned MSISDN.

##### none

Do not allow any NAM (Network Access Mode) by default.

##### cs

Allow access to circuit switched NAM by default.

##### ps

Allow access to packet switched NAM by default.

##### cs+ps

Allow access to circuit and packet switched NAM by default.

### 1.9.12 ussd default-route external EUSE

#### Command

```
ussd default-route external EUSE
```

#### Parameters

##### ussd

USSD Configuration

---

**default-route**

Configure default-route for all USSD to unknown destinations

**external**

External USSD Handler

**EUSE**

Name of External USSD Handler (IPA CCM ID)

### 1.9.13 **ussd route prefix PREFIX external EUSE**

**Command**

```
ussd route prefix PREFIX external EUSE
```

**Parameters****ussd**

USSD Configuration

**route**

Routing Configuration

**prefix**

Prefix-Matching Route

**PREFIX**

USSD Prefix

**external**

External USSD Handler

**EUSE**

Name of External USSD Handler (IPA CCM ID)

### 1.9.14 **ussd route prefix PREFIX internal (own-msisdn|own-imsi)**

**Command**

```
ussd route prefix PREFIX internal (own-msisdn|own-imsi)
```

**Parameters****ussd**

USSD Configuration

**route**

Routing Configuration

**prefix**

Prefix-Matching Route

**PREFIX**

USSD Prefix

**internal**

Internal USSD Handler

**own-msisdn**

Respond with subscribers' own MSISDN

**own-imsi**

Respond with subscribers' own IMSI

## 1.10 config-hlr-gsup

### 1.10.1 bind ip A.B.C.D

**Command**

```
bind ip A.B.C.D
```

**Parameters****bind**

Listen/Bind related socket option

**ip**

IP information

**A.B.C.D**

IPv4 Address to bind the GSUP interface to

## 1.11 config-hlr-euse